


Take note of the resolution listed on the encoder label and also which port the encoder you need to change is plugged into. You will need this information for later.




Power up the box. When prompted, press any key to continue.




The power switch is located on the back, directly under the power cord.

Reference your encoders by moving each axes so they cross at least 2 reference marks on the glass (~3").



Press the Menu button.



Use the up and down arrow keys to highlight the Installation Setup menu, and then press enter.



Use the up and down arrow keys to highlight the Encoder Setup menu, and then press the right arrow key.



Use the up and down arrow keys to highlight the port the encoder you want to change resolution on is plugged into, and then press enter.



Use the up and down arrow keys to highlight the Resolution menu, then press the right arrow key.



Use the up and down arrow keys to highlight the resolution that matches the encoder label, and then press enter twice.



Hit the left arrow key three times to get back to the DRO screen.
Repeat this sequence for additional encoders as needed.

